

Valid for 10013772, 10014407, 10022051, 203672, 202621



Read the installation instructions for the units and observe the safety information.

The target group for this installation manual is trained qualified personnel entrusted with the technical functioning and operation of the unit.

Safety instructions

Organizational measures

Risk of property damage and personal injury from lack of organizational measures

- Use equipment and protective gear suitable for the activity.

Danger of electric shock from live components.

- Prior to working on the electrical system, switch off the unit, disconnect the electrical system from the mains and prevent power from being switched on again. Check to ensure the system is dead.
- Use only insulated tools.

Opening and closing the unit



Open and close the unit according to the service instructions.

FlexFusion

→ Remove the left side wall.

SpaceSaver

→ Remove unit cover.
→ Remove the rear panel.

SpaceSaverTeam

With recirculation hood

→ Remove the rear panel.

→ Dismantle the rear wall of the hood.


Without recirculation hood

→ Remove the rear panel.

Removing the supply air area

- Dismantle the upper attachment from the supply air area (lid or screw connection).
- Disconnect the supply line from the control board or wiring harness.
- Loosen the lower clamp.
- Move the entire supply air area upwards and remove it from the side.


Overview FlexFusion, SpaceSaver



a Unit cover


b Cover supply air

Overview FlexFusionTeam - bottom



a Unit cover
b Screw fastening supply air


Remove lift magnet



a Seal cable entry
b Upper clamp
c Lower clamp
d Hose with lift magnet
e Screws mounting lift magnet
f Lift magnet
g Seal 211080
h Screw
i Washer

- Dismantle the plug of the supply line.
- Open the threaded cable connection.
- Carefully pull silicone hose upward.
- Loosen and remove the fastening screws from the lift magnet.
- Remove the washer from the lift magnet.

Install lift magnet



a Cable gland insert
b Seal
c Screw for fastening washer

- Replace seal (211080).
- Mount the sealing washer on the new lift magnet.
- Screw on the lift magnet.
- Guide cable through threaded cable connection with seal.

INFORMATION

Never operate the unit without a sealing insert in the threaded cable connection.

- Tighten the threaded cable connection.
- Mount connector.
- Mount the supply air area in reverse order.
- Connect the component electrically.